


ALEKO®

**Aluminum Outdoor
Retractable Pergola with Solar
Powered LED Lamps and
Wooden Finish - 13 x 10 Ft
Installation Manual**





Use the hex keys in the box.



You may need to use a drill for this step.




Three or more people are required at this stage.



You may need a ladder.



Do not tighten screws all the way for now.




Parts list



(A) 4X



(A1) 2X



(A2) 2X



(B) 1X



(B1) 1X



(C2) 1X



(B2) 1X



(C) 1X



(C1) 1X



(D) 2X



(D1) 2X



(E) 1X



(E1) 1X



(F) 2X



(F1) 2X



(G) 1X



(G1) 1X




(H) 5X




(H1) 5X


















(I) 4X









(V) 8X




Parts list

 (V1) 4X		 (V2) 5X	
 (J) 162X M6x16	 (K) 3X M6x30	 (L) 6X M6x85	 (M) 32X M6x15
 (N) 10X	 (O) 4X	 (P) 1X	 (Q) 1X S6 S4
 (R) 2X	 (S) 1X	 (T) 1X	 (U) 16X
 (W) 1X			

 (A) 4X
 (A1) 2X
 (A2) 2X
 (V) 8X
 (J) 64X M6x16
 (Q) 1X S4

Step 1



Don't tight screw to much when you insert A into A1 or A2 on the ground.



(I) 4X



M6x16


(J) 16X



S4

(Q) 1X

Step 2



Tight screws after A and A1 or A2 connected vertically.

Step 3



(B) 1X



(B1) 1X



(C2) 1X



(B2) 1X



(C) 1X



(C1) 1X



(V1) 4X




(R) 2X







M6x16

(J) 32X









(Q) 1X











Step 4







Step 5





(D) 2X

(D1) 2X

(V2) 2X

(J) 16X M6x16

(Q) 1X








Step 6





(M) 16X M6x15

(Q) 1X

(W) 1X



Step 7





(E) 1X

(E1) 1X

(F) 2X

(F1) 2X

(V2) 3X

M6x16
(J) 24X

S4
(Q) 1X

Step 8




M6x85
(L) 6X

S4
(Q) 1X

Step 9



Step 10


(G) 1X

(G1) 1X

(H) 5X

(H1) 5X

(S) 1X





Step 11

(J) 10X
M6x16



(K) 3X
M6x30

(Q) 1X
S4






Step 12



Step 13



NOTICE

Your proper assembly, installation and use of this structure will ensure many years of valued service from this unit. Please follow all instructions carefully and heed warnings on the carton, included in the box and sewn into the inner tent seams for your own protection and longevity of this unit.

It is built of high quality materials but must be used as intended or it's lifespan will be drastically reduced. Never climb on top of this structure. Do not rest heavy objects against the side of the structure. Failure to observe or comply with these instructions will void the manufacturer's warranty and dramatically reduce the lifespan of the unit.

This unit is not intended as a permanent structure and should not be left up for extended periods of time. It is not designed to withstand sustained winds or rain. It is a portable, temporary shelter from the sun, light rain and, in the case of screened units, flying insects.

During rain, if water begins to pool on any roof surfaces, use a blunt ended long pole, such as broom or mop, to gently push up on the roof from below to drain water.

Please utilize a minimum of three persons and a step ladder to erect this structure safely. Do not attempt to erect the structure during heavy winds or inclement weather. When the structure is erected, please use guy ropes and stakes to secure tightly at all times. If using on a solid surface such as hard ground or concrete/asphalt, be sure to use cinder blocks as anchors on each corner to which you can tie the support/guy ropes. If winds are heavier, it's a good idea to use cinder blocks in addition to ground stakes for extra anchoring support.

WARNING

Do not use candles, matches or open flames of any kind in or near a tent.

Do not cook inside a tent

Build campfires downwind and several metres away from a tent and be sure to fully extinguish campfires before leaving a campsite or before retiring for the night

Exercise extreme caution when using fuel-powdered lanterns on heaters inside a tent and use battery-operated and use battery-operated lanterns whenever possible

Do not refuel lamps, heaters or stoves inside a tent

Extinguish or turn off all lanterns before going to sleep

Do not smoke in a tent

Do not store flammable liquids inside a tent

ALEKO®

8307 S 192nd St Kent, WA 98032

Phone: 833-926-2323

hello@aleko.com

www.ALEKO.com