

ALEKO®

Portable Charcoal BBQ Offset Smoker Grill with Side Fire Box and Wooden Accents




SKU: BBQSG04









INSTRUCTIONS MANUAL

Please read all safety warnings and assembly instructions before use

This BBQ is designed for use only with charcoal




1	1 PC	2	1 PC	3	1 PC	4	1 PC	5	1 PC	6	4 PCS
											
7	1 PC	8	3 PCS	9	1 PC	10	3 PCS	11	3 PCS	12	1 PC
											
13	1 PC	14	2 PCS	15	2 PCS	16	2 PCS	17	1 PC	18	2 PCS
											
19	2 PCS	20	2 PCS	21	1 PC	22	2 PCS	23	6 PCS		
											


ASSEMBLY STEPS

Do not tie the screws too tight before completely assembly your barbecue

1.




2.




A:  M6X40 8X


3.




B:  M8 2X

4.




A:  M6X40 4X

5.




C:  M6X50 2X

D:  M6*12 7X


E:  M6 2X

6.



C:  M6X50 4X


7.



D:   M6*12 6X

F:   M4*10 8X


8.




F:   M4*10 8X

G:   M5*20 6X


9.



10.



11.



WARNING

1. Always stand the bbq on a firm level and heat proof surface. Well away from wooden fences, overhanging trees and other materials.
2. The bbq must always be under the control of a competent adult. Keep young children and pets at a safe distance once the charcoal has ignited.
3. Never use white spirit, paraffin, petrol, methylated spirit, lighter fuel or similar solvents to light the barbecue. To help ignition, only use proper bbq lighting fluid, gel or lighting blocks in accordance with the manufacturer's instructions. Never add more lighting fluid after the charcoal has been lit.
4. Most metal parts will become hot. The use of protective mitts is recommended when handling the grill, turning food etc.
5. Flare-ups will occur when hot fat drips onto the charcoal. Keep a fine jet water sprayer at hand to extinguish any flames and prevent food by burning.
6. When cooking has finished, extinguish the charcoal using a fine spray of water or by covering with sand.
7. Ensure the bbq has completely cool down before moving it and removing the charcoal ash.
8. To prolong the life of the metal parts, do not leave the bbq outside and unprotected from the weather. Ideally it should be stored in a garage or garden shed when not in use
9. This bbq is for outdoor use only!

Art.nr.101250

BBQ SMOKER

ALEKO®

8307 S 192nd St Kent, WA 98032

Phone: 833-926-2323

hello@aleko.com

www.ALEKO.com