

ALEKO° Outdoor Waterproof Bike Storage Tent

Folding Instructions









Pull the fiberglass poles out of the inserts of the tent

Flatten the tent

Hold by the outter ring in two places

Tuck the tent and pull the outter ring together





Hold the tent by outter ring in two places and lift it up vertically



Pull down the upper section inward to form a 3 layer fold



Position the 3 layers to form a circle



SKU: BSP79GR

Place the tent into the carrying bag (carrying bag included)

www.ALEKO.com

8307 S 192nd St Kent, WA 98032

Phone:833-926-2323

hello@aleko.com