





F-HW Type Of Sauna Room



1.




2.




M5x60 (6 sets)


3.




to Test to Maintain the same horizontal level




4.




M5x60 (2 sets)




5.




M5x60 (4 sets)





6.





M5x60 (2 sets)





7.



8.





9.



Wooden Stopper


10.

M5x60 (4 sets)




11.

M5x60 (8 sets)





1800



4 sets





12.



13.





14.





15.



M5x60 (4 sets)



16.




17.




18.



1 sets





2 sets






M5x60 (5 sets)

19.




20.

M5x60 (88 sets)





42 sets

21.





22.



M5x60 (4 sets)





23.





24.




25.



26.






2 sets




2 sets



27.



28.




M5x60 (14 sets)




2 sets

29.





2 sets




30.

M5x60 (8 sets)




31.


M5x60 (6 sets)




2 sets




32.




2 sets




33.




M3. 2x30 (4 sets)




1 sets




M3. 2x30 (4 sets)




1 sets



1 sets



M3. 2x30 (4 sets)



1 sets



Outdoor sauna control box and controller installation

1. It is recommended that customer shall install it in a dry and ventilated place which can avoid wind and rain.

2. The control box and controller can be installed on the wall outside the sauna room, and the rain shield should be installed above the control system to prevent rainwater from entering the control box and controller.



3. If it does not meet such conditions, it shall be installed in the sauna room according to our drawings, the control box shall be installed in the room under the bench, and the controller shall be installed in the room, the height shall not higher than 1 meter. Please keep the room dry, after each use, try to remove the moisture inside the room, or open the sauna heater for half an hour to dry the room.

34.





35.

Spread fiber glass tile(shingles)




36.

Spread fiber glass tile(shingles)





37.




38.

Spread asphalt linoleum




39.

Spread fiber glass tile(shingles)



Asphalt tiles



40.

