

# ALEKO®

# ALEKO®

8307 S 192nd St Kent, WA 98032  
Phone: 833-926-2323  
hello@alekoproducs.com  
www.ALEKO.com



SPA

Installation and user's manual

Read carefully and keep it for later reference

## SPA Installation and User's Manual

Read Carefully and keep it for later reference

Carefully read, understand, and follow all information in this user manual before installing and using the spa.

These warnings, instructions, and safety guidelines address some common risks of water recreation, but they cannot cover all risks and dangers in all cases. Always use caution, common sense, and good judgment when enjoying any water activity. Please read carefully and keep for future reference.

For your own safety and that of your product, make sure to following the safety precautions below. Fail to follow the instruction may result in serious injury, property damage or death. Improper installation or operation will void the warranty.

When using this electrical equipment, basic safety precautions should always be followed, including the following:

(a) A green coloured terminal or a terminal marked G, GR, Ground, Grounding, or the 

symbol is located inside the supply terminal box or compartment. To reduce the risk of electric shock, this terminal must be connected to the grounding means provided in the electric supply service panel with a continuous copper wire equivalent in size to the circuit conductors supplying this equipment.

\*IEC Publication 417, symbol 5019.

(b) At least two lugs marked "BINDING LUGS" are provided on the external surface or on the inside of the supply terminal box or compartment. To reduce the risk of electric shock, connect the local common bonding grid in the area of the hot tub or spa to these terminals with an insulated or bare copper conductor not smaller than No.6 AWG.

(c) All field - installed metal components such as rails, ladders, drains or other similar hardware within 3 m of the SPA or hot tub shall be bonded to the equipment grounding bus with copper conductors not smaller than No.6 AWG.

1. **WARNING** - To reduce the risk or injury, do not permit children use this product unless they are closely supervised all times.

2. A wire connector is provided on this unit to connect a minimum 8 AWG (8.4 mm<sup>2</sup>) ,6 AWG (13.3mm<sup>2</sup>) solid copper conductor between this unit and any metal equipment, metal enclosures of electrical equipment, metal water pipe, or conduit within 5 feet (1.5 m) of the unit.

3. **DANGER** - Risk of injury. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. Do

not bury the electrical cord. Locate the cord where it will not be damaged by lawn mowers, hedge trimmers and other equipment. Connect to a grounded, grounding type receptacle only.

4. **WARNING**— This product is provided with a ground-fault circuit-interrupter (on the wire near the plug).The GFCI must be tested before each use. With the product operating, open the service door. When the product stops operating, this merely indicates that the door is equipped with an electrical interlock. Next, push the test button on the GFCI and close the service door. The product should not operate. Now open the service door, push the reset button on the GFCI and close the service door. The product should now operate normally. When the product fails to operate in this manner, there is a ground current flowing indicating the possibility of an electric shock. Disconnect the power until the fault has been identified and corrected.

5. **DANGER** - Risk of accidental drowning. Extreme caution must be exercised to prevent unauthorized access by children. To avoid accidents, ensure that children cannot use this spa unless they are supervised at all times.

- Inspect the spa cover regularly for leak, premature wear and tear, damage or signs of deterioration. Never use a worn or damaged cover: it will not provide the level of protection required to prevent unsupervised access to the spa by a child. Always lock the spa cover after each use.

6.**DANGER** - Risk of Injury. The suction fittings in this spa are sized to match the specific water flow created by the pump. Should the need arise to replace the suction fittings or the pump, be sure that the flow rates are compatible.

Never operate spa if the suction fittings are broken or missing. Never replace a suction fitting with one rated less than the flow rate marked on the original suction fitting.

7. **DANGER** – Risk of Electric Shock. Install at least 5 feet (1.5 m) from all metal surfaces. As an alternative, a spa may be installed within 5 feet of metal surfaces if each metal surface is permanently connected by a minimum 8 AWG (8.4 mm<sup>2</sup>) ,6 AWG (13.3mm<sup>2</sup>) solid copper conductor to the wire connector on the terminal box that is provided for this purpose.

8. **DANGER** - Risk of Electric Shock. Do not permit any electrical appliances, such as a light, telephone, radio or television within 1.5m (5 feet) of a spa tub. Do not use the spa when it is raining, thundering or lightning.

9. **WARNING** - To reduce the risk of injury. Lower water temperatures are recommended for young children and when spa use exceeds 10 minutes. The water in a spa should never exceed 40°C (104° F). Water temperatures between 38°C(100°F) and 40°C(104°F) are considered safe for a healthy adult.

## WARNING

- Since excessive water temperatures have a high potential for causing fetal damage during the early months of pregnancy, pregnant or possibly pregnant women should limit spa water temperatures to 38°C(100°F).
  - Before entering a spa or hot tub the user should measure the water temperature with an accurate thermometer since the tolerance of water temperature regulating devices varies.
  - The use of alcohol, drugs or medication before or during spa use may lead to unconsciousness with the possibility of drowning.
  - Obese persons or persons with a history of heart disease, low or high blood pressure, circulatory system problem, or diabetes should consult a physician before using a spa.
  - Persons using medication should consult a physician before using a spa since some medication may induce drowsiness while other medication may affect heart rate, blood pressure, and circulation.
  - Check with doctor before use if pregnant, diabetic, in poor health, or under medical care.
- 10.WARNING - To reduce the risk of electric shock, do not use an extension cord, timers, plug adapters or converter plugs to connect the unit to electric supply; provide a properly located outlet. Portable whirlpool baths and swimming pools with incorporated heating elements must be connected to a grounded mains supply socket with a supply cord fitted with a plug and GFCI with a tripping current of 10mA.**
- The spa electrical appliance should be supplied through a ground-fault circuit-interrupter (GFCI) having a rated residual operating current not exceeding 30mA.
- Parts containing live parts, except parts supplied with safety extra-low voltage not exceeding 12V, must be inaccessible to occupants in the spa.
- Parts incorporating electrical components, except remote control devices, must be located or fixed so that they cannot fall into the spa.
- Residential electrical connection box must be located safely with a distance of at least 2m away from the spa.
- Electric installation should fulfill the local requirement or standards.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- To reduce the risk of child drowning, supervise children all times. Attach and lock spa cover after each use.
- Make sure the floor is capable of supporting the expected load ( $\geq 500\text{kg/m}^2$ ).
- Adequate draining system must be provided around the spa to deal with overflow water.
- People with infectious disease should not use a spa or hot tub.
- To avoid injury exercise care when entering or existing the spa or hot tub.
- Water temperature in excess of 40°C(104°F) may be injurious to your health.
- Never use a spa or hot tub alone or allow others to use the spa alone.

## IMPORTANT SAFETY INSTRUCTIONS

- Do not use a spa or hot tub immediately following strenuous exercise.
- Do not put the spa under 0°C(32°F) environment in order to avoid freezing if there is still water in the pool.
- Do not turn on the spa when the water is frozen.
- Never pour water with a temperature higher than 40°C(104°F) into the spa directly.
- Always unplug this product from the electrical outlet before removing, cleaning, servicing or making any adjustment to the product.
- Never jump or dive into a spa or any shallow body of water.
- Do not attempt to plug in or unplug this product while standing in water or when your hands are wet.
- Do not use the spa if damaged in delivery and/or malfunctioning in any way. Keep all pets away from the spa to avoid any damage.
- Do not add bath oil or bath salt to the spa water.
- In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

- WARNING: CHILDREN SHOULD NOT USE SPAS OR HOT TUBS WITHOUT ADULT SUPERVISION
- WARNING: DO NOT USE SPAS OR HOT TUBS UNLESS ALL SUCTION GUARDS ARE INSTALLED TO PREVENT BODY AND HAIR ENTRAPMENT
- WARNING: PEOPLE USING MEDICATIONS AND/OR HAVING AN ADVERSE MEDICAL HISTORY SHOULD CONSULT A PHYSICIAN BEFORE USING A SPA OR HOT TUB
- WARNING: PEOPLE WITH INFECTIOUS DISEASES SHOULD NOT USE A SPA OR HOT TUB
- WARNING: TO AVOID INJURY EXERCISE CARE WHEN ENTERING OR EXITING THE SPA OR HOT TUB
- WARNING: DO NOT USE DRUGS OR ALCOHOL BEFORE OR DURING THE USE OF A SPA OR HOT TUB TO AVOID UNCONSCIOUSNESS AND POSSIBLE DROWNING
- WARNING: PREGNANT OR POSSIBLY PREGNANT WOMEN SHOULD CONSULT A PHYSICIAN BEFORE USING A SPA OR HOT TUB
- WARNING: WATER TEMPERATURE IN EXCESS OF 38°C MAY BE INJURIOUS TO YOUR HEALTH
- WARNING: BEFORE ENTERING THE SPA OR HOT TUB MEASURE THE WATER TEMPERATURE WITH AN ACCURATE THERMOMETER
- WARNING: DO NOT USE A SPA OR HOT TUB IMMEDIATELY FOLLOWING STRENUOUS EXERCISE
- WARNING: PROLONGED IMMERSION IN A SPA OR HOT TUB MAY BE INJURIOUS TO YOUR HEALTH
- WARNING: DO NOT PERMIT ELECTRIC APPLIANCES (SUCH AS A LIGHT, TELEPHONE, RADIO, OR TELEVISION) WITHIN 1.5 M OF THIS SPA OR HOT TUB
- CAUTION: MAINTAIN WATER CHEMISTRY IN ACCORDANCE WITH MANUFACTURER' S INSTRUCT ION

**SAVE THESE INSTRUCTIONS**

EN

## 2. PACKAGE LIST

### 1.1. Specifications

	4 persons	4 persons	6 persons	2+1 persons
Model	17609XX	17624XX/ 17625XX 17626XX/ 17627XX	17610XX / 17628XX 17629XX / 17630XX	17612XX 17623XX
Capacity	4 persons	4 persons	6 persons	2+1persons
Dimension (outer)	66.1" × 66.1" × 27.6" 168 × 168 × 70 cm	Ø 68.9" × 27.6" Ø 175 × 70 cm  Ø 65" × 27.6" Ø 165 × 70 cm(17624XX)	Ø 80.3" × 27.6" Ø 204 × 70 cm	Ø 65" × 27.6" Ø 165 × 70 cm
Dimensions (inner)	50.3" × 50.3" × 27.5" 128 × 128 × 70 cm	Ø 53.1" × 27.5" Ø 135 × 70 cm	Ø 62.9" × 27.5" Ø 160 × 70 cm	Ø 49.2" × 27.6" Ø 125 × 70 cm
Water capacity	700 L	800 L	956L	686 L
Power supply	110-120 V,60 Hz,1380W	110-120 V,60 Hz,1380W	110-120 V,60 Hz,1380W	110-120 V,60 Hz,1380W
Max heat temperature	40°C	40°C	40°C	40°C
Test certificate	cETLus	cETLus	cETLus	cETLus
Heating efficiency Ambient temperature : 20°C	1-2°C/h	1-2°C/h	1-2°C/h	1-2°C/h



This appliance is marked according to the European directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE). This symbol indicates that this appliance may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. Disposal of the appliance shall be carried out in accordance with the local environment regulations for waste disposal.

### 2.1. Package list

Ensure to check all parts are present:



Liner



Pump Unit



Top Cover



Ground Cloth



GFCI



Air Valve



Inflating Hose



Pump Unit Connectors



Caps



Repair Kit



Filter Cartridge



Filtration Cartridge Support

Hyperthermia occurs when the internal temperature of body reaches a level several degrees above the normal body temperature 37°C(98.6°F). The symptoms of hyperthermia include an increase in the internal temperature of body, dizziness, lethargy, drowsiness, and fainting. The effect of hyperemia include failure to perceive heat; failure to recognize the need to exit spa; unawareness of impending hazard; fetal damage in pregnant women; physical inability to exit the spa; and unconsciousness resulting in the danger of drowning. **WARNING-** The use of alcohol, drugs, or medication can greatly increase the risk of fatal hyperthermia.



### 3. INSTALLATION

**3.1. Site selection WARNING:** Before proceeding to install your spa, please make sure that the selected location meets the following conditions:

- A level place in order to avoid any defect, tearing or leakage.
- Wide enough to support the spa and its pump unit.
- Able to support more than 500 kg/m<sup>2</sup>.
- Sheltered from the sun and bad weather.
- Clean and free from sharp objects.
- Devoid of excessive vegetation on the ground.

Failure to comply with these rules may result in property damage or personal injury.



Use a sun cover



Place in a clean environment



Ensure its level

**WARNING:** The GFCI plug must be tested before each use... Do not use if GFCI test fails and see chapter 6.1.

1. Insert the plug into the power outlet.
  2. Press the «RESET» button, the indicator light turns red.
  3. Press the «TEST» button, the indicator light turns off.
  4. Press the «RESET» button, the indicator light turns red.
- The GFCI works properly.

### 3.2. Assembling



1) Unfold the inflatable spa over the base protector - IMPORTANT



2) Bring the pump unit to the inflatable spa



3) Connect the inflation hose to the pump on the socket



4) Insert the inflation hose into the inflatable spa



5) Connect the pump unit, then press the button to inflate the spa. The air flow valve prevents your spa from over-inflating.




6) Inflate the inflatable spa for about 10 minutes. Ensure that the spa is firmly inflated. For 'California' use hand pump and blow to 10 PSI.



7) Remove the inflation hose and screw the cap firmly in place



8) Connect the unit pump to the spa using the 3 connectors to screw in. Ensure the icons on the pump and the spa match up




9) Attach the filter cartridge in the spa, it can be pressed and screwed in place. Ensure filter is in filter housing



10) Ensure that the drain caps are properly closed before filling the spa




11) Fill the spa with 10 cm of water.



12) Smooth wrinkles out of the bottom of the spa, then fill the spa to the level indicated. Your spa is ready

## 4. USAGE

### 4.1. Control panel



### 4.2. Functions

Once powered-up, the LED displays the current water temperature automatically.



The temperature unit's selector changes the temperature units from Celsius degrees to Fahrenheit degrees.



Press the temperature adjustment buttons, then the screen will flash. When it is flashing, you can set the desired temperature. The value will increase or decrease 1 degree at once. The temperature could be set between 30°C to 40°C (86°F to 104°F).



To lock or unlock the control panel, press the Lock button and hold 3 seconds. **Lock the control panel when you are away to prevent other people come to change your settings.**



Press the Bubble button to activate the bubble and massage system, the green indicator light turns on. It can be turned off by pressing it again.

The bubble system will stop automatically after 30 minutes of operation. Re-activate the bubble function by pressing the bubble button again.

When the filter button is on, pressing bubble button will alter the filter mode into bubble mode. The filter indicator light will turn off and the bubble indicator light will turn on. If the bubble button is pressed again, the bubble mode will be changed back to the filter mode.



Press the filter button to activate the water filtration. The green indicator light will turn on when the filtration system is activated. Please note that filters should be changed every 7 days, or until they become discolored.

*Note:*

- If bubble function is on, the filtration can't be activated.



Press the heating button to activate water heating and filtering system at the same time. The green indicator light of filter and red indicator light of heating will turn on at same time

The pump does not stop heating until the current water temperature reaches the set temperature; and the heating system will restart after the current water temperature drops 2°C below the set temperature automatically.

Maximum heating temperature: 40°C (104°F)

**Important:**

**After 150 cumulative hours of filtration operations, an audible alarm will sound and the LCD display will show the characters CHG, followed by FIL, to remind you to change or clean the filter. You can hold the filtering button 5 seconds to turn off the buzzing. The filtering system will turn off, you can press the button to activate the filtering system again.**

*Note:*

- With the heating system starting, the filtration system will start working together.

- After turning off the heating system, the filtration system will still work.

- If the bubble function is active, the filtration and heating functions cannot be activated.

### 4.3. Spa cover and security

After each use, the control panel must be locked and the spa must be covered with its top cover and it must be attached to the base protector with the safety buckles.

Each safety buckle has a lock system; To close the buckle, put the latch in an up position which locks the buckle, Put the latch in a down position to unlock the buckle.

The top cover retains the heat from the water and secures the spa.



EN



## 5. MAINTENANCE

### 5.1. Water maintenance

**WARNING: Bad spa water quality can harm your health.**

Depending on the frequency and conditions of use:

- The filter cartridge should be regularly cleaned / replaced every 150 hours max.
- The filter cartridge should be replaced every 150 hours unless cleanable.
- The spa water should be changed every 15 to 30 days.

Use a water test kit to control the parameters of the water before using the spa, or at least once a week.

Use disinfection products for the spa. The treatment products should be used with caution and it is imperative to refer to their instructions.

Damage resulting from improper use of treatment products is not covered by the warranty

#### 1. Water balance

The water balance (pH) must be maintain between 7 and 7.4.

#### 2. Water Sanitation

To sanitise the spa water, we suggest using an active oxygen-based treatment or bromine placed in a floating dispenser. (Dispenser sold separately).



### 5.2. Cleaning and replacing the filter cartridge

A dirty filter cartridge may contaminate the spa water and cause damage to the heating function.

1. Unscrew the filter case by turning it anti-clockwise. Take out the filter cartridge from the case.
2. Rinse off the filter cartridge with a garden hose. If the filter cartridge remains dirty and discolored, the **filter cartridge should be replaced**.
3. Put back the cleaned filter cartridge into its case and screw it to the spa.



#### 5.2a Disinfection

Water Sanitation:

To sanitise the spa water, we suggest using an active oxygen-based treatment or bromine placed in a floating dispenser. (Dispenser sold separately)

Seek professional advice and guidance before doing this.

Attention:

Detergent residues and dissolved solids from bathing suits and chemicals may build up on the spa walls. Use soap and water to clean the walls and rinse thoroughly with a garden hose using a direct powerful water spray.

### 5.3. Drainage and storage

#### Drainage

- 1 Check the stopper on the bottom of the spa and the drain cap.
- 2 Unscrew the drain cap.
- 3 Remove the stopper on the bottom of the spa. Completely drain all water from the spa.
- 4 Once empty, the spa can be cleaned with soap and water.



#### Storage

- 5 Press the bubbling button to blow out the water inside the jet holes. Unplug the pump, remove the filter cartridge from the inner wall of the spa.
- 6 Use a towel to wipe off the spa, dry for 24 hours.
- 7 Unscrew the valves to deflate the spa.
- 8 Fold the spa.

It is recommended to store the spa in its original package in a warm dry place.



### 5.4. Repair kit

Little holes or punctures can be repaired with the repair kit included and glue can be adhered to the spa liner.

1. Find the leak.
2. Thoroughly clean the area surrounding the leak.
3. Cut a piece of repair material in round shape, which should be larger than the damaged area.
4. Apply adhesive to the back of the patch and around the area to be repaired.
5. Put the patch on the damaged area and press down firmly. Allow 12 hours for repair to dry. After the patch has dried, apply glue around the edges for a complete seal (dry 4 hours). Ensure NO bubbles are left under the patch.

## 6. TROUBLE SHOOTING

### 6.1. Troubleshooting

Here are some useful tips to help you to diagnose and rectify common problems

#### Reference

Inlet – The inlet is where the filter is attached

Outlet – The water outlet is directly above of the filter and is where the hot water is recirculated back into the spa from the heater unit.



Problem	Cause	Solution
Control panel screen does not operate	Check power source	Power failure
		Reset the GFCI plug / Check if the wiring system is adapted to the power of the pump unit (1540W)
		Contact service centre for service if it does not reset
SPA pump does not heat properly	Temperature set is too low	Set to a higher temperature
	Filter Cartridge is dirty	Clean or Replace the cartridge (see chapter 5.2)
	Too low water level	Fill water to minimum water level
	Heating element defective	Contact service centre
Bubble system does not work	Pump is overheating	Cut off the power and wait until the pump has cooled.
	Auto shut-down feature (30min) is activated	Press the bubble button to reactivate
	Malfunction of the pump unit	Contact service centre if it does not reset
Water filtration does not work	Filter Cartridge is dirty	Clean or Replace the cartridge (see chapter 5.2)
	Inlet and outlet blocked	Clean the inlet and outlet
	Air inside the pump	Fill water to minimum water level
	Malfunction of the pump unit	Contact service centre if it does not reset
Pump leakage	Adaptor seal in wrong position	Replace the seal in the right position
	Water leakage from pump body	Check the pump body, Contact service centre
Spa leakage	Spa is torn or punctured	Use provided repair kit (see chapter 5.4)
Water is not clean	Insufficient filtering time	Filters must be changed once a week
	Filter Cartridge is dirty	Clean or Replace the cartridge (see chapter 5.2)
	Spa filled water quality	Change the spa water completely
	Improper water treatment	Refer to the chemical manufacturer's instructions

## 7. WARRANTY

### 7.1. Error codes

If the screen displays an error code “Ex”, please refer to the table below.

Code	Situation	Problem	Causes	Solutions
E1	Not heating properly.	Wrong temperature control sensor.	Temperature control sensor short circuit or open circuit.	Contact Service centre.
E3	Not heating properly.	High water temperature indicator.	1.The filled water is over 45°C (113°F) 2.The filter cartridge was put on the wrong suction fitting (higher suction fitting).	1.Cut off the power, make sure the spa water is between 2°C~44°C(36°F~111°F).If this does not solve the problem, refer to the box below. 2.Put the filter cartridge on the lower suction fitting.
E4	All functions do not work, buzzing warning.	Low water temperature indicator.	The spa water is lower than 2°C (36°F).	Cut off the power, make sure the pool water is between 2°C~44°C (36°F~111°F) · If this does not solve the problem, refer to the box below
E5	All functions do not work, buzzing warning.	High water temperature indicator.	The filled water is over 50°C (122°F).	Cut off the power, turn to qualified electrician to reset the thermal cutout. If this does not solve the problem, refer to the box below
E6	Not heating and filtering properly Buzzing warning.	Water pressure is not big enough to activate heating.	·Inlet or outlet on inner wall are blocked. ·Filter cartridge is too dirty. ·Spa water does not reach minimum water level. ·Do not release air from pump Pump is wrong”	·Clean inlet and outlet ·Clean or replace the filter cartridge ·Add water to reach water level ·Do air release as outlined again · If this does not solve the problem, refer to the box below

#### E3, E4, E5, E6 error code

Cut off the electricity for 5 minutes and re connect

If error code is still displayed on the control box, please adhere the following instructions:

1 - Check that the water line is between the high and low limits.

2 – Clean or replace the filter cartridge

3 - Unscrew and clean the 2 nozzles (entry and exit of water) inside the spa and remove any waste if necessary (hairs, fur, skin...)

5 - Check that the propeller on the filter pump does not contain foreign matter.

Cut the spa again electrically for 5 minutes and re-connect it, if the error code is still displayed on the control box please contact the Service Centre.



## 7.2. Warranty

Avenli products have been inspected and found free of defects prior to leaving the factory. Avenli warrants this product against defects in material and workmanship for a period of time, 1 year for the pump and 6 months for the liner, unless local law has special requirement. Avenli warrants this product begins on the date of purchase and Avenli requires presentation of the original proof to purchase to ascertain the date. During the warranty period, Avenli will either repair or replace, at its discretion, any defective produces. Replacement products or repaired parts will be warranted for only the unexpired portion of the original warranty.

### Shipping cost policy

The return of defect parts to the authorized service center is at the charge of the owner. On warranty period, the return is at the charge of service center.

### Warranty policy

This limited warranty does not apply to any defect resulting from negligence, accident, misuse, or other reason beyond Avenli's reasonable control, included but not limited to: normal wear and tear, negligence or failure to follow the product instructions, improper or inadequate maintenance; connection to improper power supply; chemical water damage, loss of pool water, unauthorized product modification or repair; use for commercial purpose; fire, lightening, flood or other external causes.

This warranty is valid only in the country of purchase in such countries where Avenli sells and services the same model with identical technical specifications.

Warranty service outside the country of purchase is limited to the terms and conditions of the corresponding warranty in the country of service. Where the cost of repairs or replacement is not covered by this warranty, Avenli will advise the owners and the cost shall be charged to the owner.

This warranty only applies to the original purchaser and terminates upon any transfer of ownership.

All repairs of which warranty claims are made must be pre-authorized by a Avenli service center.

All the authorized selling dealer is responsible for all in-field service work carried out on your Avenli product. Avenli will not be liable for results of cost of workmanship from unauthorized service person.

### Warranty registration

To validate your warranty, please register your product on our website :[www.aleko.com](http://www.aleko.com). It is essential that all informations including customer name, date of purchase, serial number, spa model are indicated. Without these information the warranty will be invalid.

Local after-sales service center

[www.aleko.com](http://www.aleko.com)

